



GPRS/CSD/SMS security module GT7

User manual

Module version 1.26

Security module GT7 transfers security control panel data to monitoring station via GSM network.

- Primary alarm transmission channel to monitoring station: either GPRS or CSD or SMS.
- Back-up alarm transmission channel to monitoring station: either GPRS or CSD or SMS.
- Signal strength and operating failure display.
- Alarm transmission to monitoring station by 2 IP addresses and 2 GSM modem phone numbers.
- Alarm transmission to up to 4 mobile phones by text SMS.
- Remote configuration by GPRS connection is possible.
- Remote uploading/downloading of firmware by GPRS connection is fully supported.
- Multilingual configuration software.
- Simple installation by 4-wire serial connection.

Principles of operation

Communicator GT7 receives data from:

- Common bus:
Compatible with: DSC® PC585, PC1565, PC5020, PC1616, PC1832, PC1864.
PYRONIX® MATRIX 424, MATRIX 832, MATRIX 832+, MATRIX 6, MATRIX 816.
GE® CADDX NX-4, NX-6, NX-8.
- Serial output:
Compatible with: PARADOX® SPECTRA SP5500, SP6000, SP7000, 1727, 1728, 1738.
PARADOX® MAGELLAN MG5000, MG5050.
PARADOX® DIGIPLX EVO48, EVO192, NE96, EVO96.
PARADOX® ESPRIT E55, 728ULT, 738ULT.
- Telephonic communicator
i.e. control panel transfers data to GT7 communicator through C11 interface.
- Outputs (PGMs),
i.e. communicator transfers signal regarding the change of input state, having received it through input expander CZ6.

Security module GT7 sends information, received from the control panel, to monitoring station by either GPRS or CSD or SMS. If the connection has failed, communicator will repeatedly attempt to restore it for **n** times (number of attempts (**n**) can be set). If the module GT7 fails to restore connection, the module will automatically connect to the back-up channel and send the unsent messages through it. Duration of connection or attempts to connect to the back-up channel can be set, after which the communicator tries again to connect to the primary channel.

Security module GT7 sends signals PING for testing of communication. Messages sent to monitoring station correspond to Contact ID table of codes.

Message receivers:

- Software based IP receiver **AGSR (Alarm GSM Signals Receiver)**. Free AGSR receiver software available to operate with practically any central station software. This software is designed to convert data received via GPRS to serial RS232 or Ethernet TCP/IP . The software emulates Surgard MLR2-DG. This is free software and available with purchase of GT7 module. Please contact us at info@orvos.ee
- Hardware based receiver **Linux AGSR10**.

Module can transform the data, received from the security panel, to text SMS messages and send them to up to 4 mobile phones. Text of SMS message (name of object, user names, partitions names, event descriptions) can be specified by the User.

Package content

- Security module GT7, (the SIM card is not included)
- GSM straight antenna,
- 2 fittings DIN 7985 M3x6,
- Velcro type stick-on (two-sided x10 cm).

Specifications

Power supply	DC 12 V
Current	up to 60 mA (stand-by running) up to 500 mA (by alarm transmitting)
Frequency	850/900/1800/1900 MHz
Primary reporting channel to CMS	either GPRS or CSD or SMS

Back-up reporting channel to CMS	either GPRS or CSD or SMS
Alarm transmission to 4 mobile phones	by text SMS
Storage	up to 60 messages
Input	1, NC type
Output	1, OC type, switching 30V DC and 100 mA
Operating environment	from -10°C to 50°C, relative air humidity 80% when +20°C
Dimensions	85 x 65 x 25 mm

Description of the communicator GT7



GSM antenna connector
LED indicators,
Terminal block
SIM card holder
USB socket

Description of terminals block


Clamp	Meaning
+E	+12V supply clamp
Com	Common (device ground) clamp
Clock	Synchronizing signal clamp
Data	Data signal clamp
IN	Input clamp (NC type)
OUT	Output clamp (OC type)

Operation of light indication


LED1	LED2	Meaning
OFF	Red flashing	No SIM card
Yellow ON	OFF	Configuration mode
Yellow flashing	OFF	Registering to GSM network
Yellow ON	Red ON	Communication has failed
Yellow ON	Green ON	Data transmitting mode
Green ON	Green ON	Stand-by
Green ON	Red and green flashes by arrangement	Number of red flashes indicates GSM signal level

Fitting to control panel's case


1. Set operation parameters.	see chapter "Module configuration "
2. Put activated SIM card into a holder as shown in the picture.	 <p>Note:</p> <ol style="list-style-type: none"> 1. Ask your GSM provider about SIM card properties before transferring data via chosen channel. 2. Disable PIN code request if necessary.

3. Fit to control panel's case.	Drill holes on control panel's case. 
4. Screw on the GSM antenna.	
5. Connect wires to control panel.	See wiring diagrams
6. Switch on power supply.	
7. According to LED indications, check GSM signal level. Test data transmission.	Note: If GSM signal level is not sufficient, connect other type antenna.


Wiring diagrams




Wiring diagram to **DSC®**
Compatible with: PC1616, PC1832, PC1864, PC585, PC1565, PC5020.



Wiring diagram to **Paradox®**
Compatible with: SPECTRA SP5500, SP6000, SP7000, 1727, 1728, 1738, MAGELLAN MG5000, MG5050, DIGIPLEX EVO48, EVO192, EVO96, NE96, ESPRIT E55, 728ULT, 738ULT.



Wiring diagram to **Pyronix®**
Compatible with: MATRIX 424, MATRIX 832, MATRIX 832+, MATRIX 6, MATRIX 816.



Wiring diagram to **Caddx®**
Compatible with: NX-4, NX-6, NX-8.

Module configuration

Operational parameters can be set, read, modified and updated by using configuration software ConfigGT7. Configuration is possible by two methods: when communicator GT7 is connected to PC on-site using USB cable and when communicator GT7 is remotely connected to IP receiver AGSR by GPRS connection.


www.orvos.ee / info@orvos.ee

Configuration software ConfigGT7 installation. Download file *ConfigGT7_setup.exe* from www.orvos.ee and follow the installation wizard.

USB driver installation. Microchip® USB drivers *mchpcdc.inf* are required for module GT7 USB connection to PC. If Microchip® USB drivers have never been installed to PC before, *Windows New Hardware Wizard* window will appear. To finish the installation choose “Yes, this time only”, click Next and follow the installation wizard.

Setting operation parameters when connecting by USB cable

1. Switch on power supply.
2. Run the configuration software ConfigGT7.
3. Choose the dialog language in window *Main/Settings/Language*.
4. Connect communicator to PC using USB cable.
5. Set parameters of comport in window *Main/Settings/Comport*.



[Name] – write name of comport, if it's necessary (eg. GT7_USB).

[Port] – select comport communicator GT7 is connected to (eg. COM2).

[Baudot rate] – 115200.

[Data bits] – 8.


[Stop bit] – 1.

[Parity] – None.

[Flow control] – None.

Click button [Apply].

6. Click icon [Connect/Disconnect].
7. Click icon [Read] to read existing parameters. Enter access code to allow configuration in the appeared window (default 1234).
8. Enter common communicator parameters in window *Main*.



Enter account number [Account]. Check box [Hex], to allow hexadecimal entering.

Enter SIM card PIN code [SIM Card PIN]. If PIN code request is disabled, leave it blank.

Select the type of connected control panel from the list [Panel type].

Select a PING transmission to monitoring station channel [GPRS, CSD, SMS ping time] and enter PING transmission period.

Check the box [Test time] to activate message transmission *Test* function and specify the transmission period.


Enter a number of attempts the communicator will try to restore primary communication after it has failed [Backup reporting after]. After this number of attempts, the communicator will try to connect to a back-up channel for reporting.

Check the box [Save access code] in order for PC to remember the access code.

When the box [Read after connection] is checked, configuration parameters will be automatically read after connection.

Click the button [Restore] in order to restore default parameters.

9. Select primary and back-up data transmission channel in window *Reporting/GPRS&GSM reporting* and set parameters of network and receivers.



Select primary data transmission channel [Primary reporting].

Select back-up data transmission channel [Backup reporting].

In active fields:

Enter receiver IP address [Server IP address or Domain].

Enter the receiver port [Port].

Enter GSM modem SIM card number [Tel]. Order: country code (without +), network operator's code, local number.

Enter access point name [APN]. Fill fields [User Name], [Password], [DNS1] and [DNS2] by request of service provider or leave them blank.


Select transmission protocol from the list [Protocol].

Enter a 6-digit data encryption code [Encryption key]. Note: this key has to be the same as entered into IP receiver.

Enter a duration of connection to the back-up channel [Return to primary after]. When this time has expired, communicator starts to restore connection to primary channel.

To modify and activate communicator generated messages (list [Special event codes]), open the window by double clicking on selected event's row and fill the appeared window.

10. Enter 4 phone numbers by which monitoring station will be able to activate GPRS connection between communicator and IP receiver for configuration. Fill fields *Settings/CMS Phones*.




Enter up to 4 phone numbers [T01], [T02], [T03], [T04]. Sending a specified form SMS message from a phone, which number is in this list, allows activation of GPRS connection between communicator and IP receiver.

If fields are left blank, this allows activation of GPRS connection by sending SMS out of every mobile phone.

Order: country code (without +), network operator's code, local number.

11. Specify distribution of the reports by type and user groups for the communicator to transfer control panel data to mobile phone by SMS in specific order. Fill the window *Reporting/Text SMS reporting*.




Specify distribution of messages by type and phone numbers, i.e. to whom the what type of messages should be transferred. Check the table [Name]

Enter phone numbers [T1], [T2], [T3] and [T4]. Order: country code (without +), network operator's code, local number.

Enter object name [Account] (this true name will be shown in the SMS message text when it is received).

Fill the list [Partitions] to start create texts of SMS messages transferred. It's possible to change texts written in [Area1, ..., Area16] (these true names will be shown in SMS message text when it is received). If partitions are not created, leave the list blank.

12. Fill lists in window *Reporting/Users&Zones* to create SMS message texts transferred to mobile phone.



Enter user names by access codes who will have possibility to arm/disarm the security system [User1, ..., User16] (these true names will be shown in SMS message text when it is received).

Enter names of security zones [Zone1, ..., Zone16] (these true names will be shown in SMS message text when it is received).

13. Click icon [Write] or function key [F6] to enter the set parameters into communicator's memory.

14. Click icon [Save] or function key [F5] to save the set parameters to file with extension ".gst".

15. Click icon [Disconnect] or function key [F8] to disconnect from the communicator GT7.

Click icon [Open] or function key [F3] to open a saved configuration file. Click icon [F4] or function key [F4] to open the last saved configuration file.

Setting operation parameters remotely when connected by GPRS connection

Remote configuration can be done by using software ConfigGT7, when there is an active GPRS connection between IP receiver AGSR and the communicator GT7. Send an SMS message in appropriate form to activate GPRS connection. Communicator will only respond to SMS messages if it receives a message from a phone whose number is entered into *Main/Settings/CMS Phones* list. If the above discussed list is blank, communicator will respond to SMS in an appropriate form from any mobile phone. When GT7 receives this message, it initialises the GPRS connection with IP receiver AGSR.

SMS structure:

CONNECT _{space} **1234** _{space} **SERVER=100.100.100.100** _{space} **PORT=1000** _{space} **APN=provider** _{space} **USR=user** _{space} **PSW=psw** _{space} **ENCR=enc**

Description:

- write the initial command (word "CONNECT"),
- write the 4-digit configuration access code (default 1234),
- write the word "SERVER=" and receiver IP address from which the configuration will be done (instead of symbols "100.100.100.100" written in example)
- write the word "PORT=" and port of receiver from which the configuration will be done (instead of "1000"),
- write the word "APN=" and access point name (APN) (instead of "provider"),
- write the word "USR=" and APN User name if required by the provider (instead of "user"),
- write the word "PSW=" and APN Password, if required by the provider (instead of "psw"),
- write the word "ENCR=" and 6-digit data encryption code (default 123456) (instead of "enc").

- Notes:
1. The word _{space} means space interval between symbols.
 2. If provider does not require APN User name and Password, text "..._{space}USR=_{space}PSW=_{space}..." have to be written accordingly in the SMS message.

Actions after the SMS has been sent:

1. Open the main window of IP receiver AGSR and select the row of communicator which parameters will be set.
2. Run configuration software ConfigGT7 by right-clicking on the appeared icon [ConfigGT7].

The image shows two screenshots of software interfaces. The top screenshot is the 'Alarm GSM Signals Receiver (AGSR)' window. It features a menu bar (File, Settings, About), a 'Control' section with 'Refresh control' and 'Refresh' buttons, and an 'Objects control' section with a 'Remove object' button. A table lists objects with columns: Object ID, IP, Phone number, Communication state, Level, GPRS last ping, GPRS ping interval, GSM last ping, GSM ping interval, and Device. The first row shows Object ID 1234, IP 194.150.65.8, and a 'ConfigGT7' icon. Below the table, there are checkboxes for 'Show incoming events' and 'Show incoming PING's', followed by a log of events. The bottom status bar shows: GPRS device status: Active, GSM device status: Inactive, External COM port status: Inactive, External TCP status: Inactive.

The bottom screenshot is the 'ConfigGT7' window. It has a menu bar (File, About) and a toolbar with buttons: Connect/Disconnect [F2/F8], Read [F7], Open List [F4], Write [F6], Open [F3], and Save [F5]. The 'Main' tab is active, showing fields for Account (FFFF), SIM Card PIN (0), Access Code (0), and Panel type. There are checkboxes for Hex, GPRS ping time, DATA ping time, SMS ping time, and Test time, each with a corresponding time input field. A 'Backup reporting after' field is also present. At the bottom, there are checkboxes for 'Save access code' and 'Read after connection', and a 'Restore defaults settings' button. The status at the bottom is 'Disconnected'.